



Mega Jaws Bottle Crusher Guidelines.



➤ General Operating Steps.

 Always wear **gloves** and **eye protection** to protect hand from sharp glass cullet and **ear protection** from excessive noise levels when using the bottle crusher. 



1. Daily inspections should be performed, this should include a visual inspection of all power leads, nuts and bolts.
2. Ensure the machine receives a consistent supply of electricity, we would recommend the machine is not used with an extension lead to ensure an extended life of the motor capacitors.
3. Ensure there is an empty 140 litre bin in the bin cabinet.
4. Ensure the door is closed and that the door safety limit meets correctly.
5. Make sure the e-stop button is released.
6. Press the green (on) button. This will start the crusher motor and dust extraction fan motor.
7. Only when the Bottle crusher is running should Bottles be loaded into the hopper funnel and will be crushed instantly.
8. When the operator is finished, the machine is stopped by pressing the e-stop.
9. Should in the event of a power surge or thermal overloads of the motors' happen there is two independent motor overload reset button on the underside of the electrical panel. Should the buttons trip, leave the machine 10mins to cool down and then press the reset button.

➤ Cleaning & Maintenance Steps

⚠ Always wear **gloves** and **eye protection** to protect hand from sharp glass cullet and **ear protection** from excessive noise levels along with a **dust mask** when cleaning and maintaining the bottle crusher. **⚠**



1. It is recommended that the ‘Mega Jaws’ Bottle Crusher be thoroughly cleaned after every 5000 bottles.
2. Put an empty 140L bin into base of the machine.
3. Start Mega Jaws as per normal operating instructions.
4. Pour 10 ltrs warm water with cleaning detergent into hopper, and allow to circulate through mega Jaws.
5. Turn-off Mega Jaws bottle crusher & isolate from the power source.
6. Wipe down Mega Jaws with damp cloth.
7. Sweep away any loose glass debris from inside the bin chamber.
8. **⚠** Wearing a dust mask, open and empty out the dust content of the extractor **⚠**
9. Replace the dust filter at least once per year.
10. Re-connect to the power supply.
11. Mega Jaws is now ready to start crushing glass bottles again.